



Gently pry on each end of the existing chip to remove it from the socket.



Note the notch on the end of the Socket.

Make sure that the notch on the end of the new chip is on the same end as the notch in the socket and install the new chip. Press in firmly to make sure the chip is all of the way in the socket.